


NISSAN

JUKE

TYPE: F16, 5-door SUV

(2019 -)





| | Airbag | A | Stored gas inflator | _ | eat belt tensioner | | SRS | control unit | | Pedestrian protection active system |
|---|---|--------------|--------------------------------------|---|-----------------------|------------|-----|-----------------------------|---------------|---|
| | Automatic rollover protection system | | Gas strut / Preloaded spring | High st | trength zone | | | e requiring al attention | | |
| 000 | Battery low voltage | | Ultra-capacitor, low voltage | Fi | uel tank | | C | ias tank | X | Safety valve |
| | Battery pack, high voltage | N | High voltage power cable / component | High voltage device that disconnects High voltage | | | | oox disabling h voltage | | High voltage ultra-capacitor, |
| | Fuel tank content Gasoline / Ethanol | | | | | | | | | |
| NISSAN AUTOMOTIVE EUROPE SAS in co-operation with Moditech Rescue Solutions Nov2020 | | | | Document N° | | Version N° | | Page N° | | |
| | | | | SJNxAAF16x1xxxxxx | | 03 | | 1/4 | | |

Nissan Juke Type: F16, 5dr SUV (2019 -) - Additional Pages

1. Identification / recognition




2. Immobilization / stabilization / lifting

Immobilize vehicle:

- 1. Block wheels
- 2. For automatic transmission select the P (park) position
- 3. Set parking brake
- 4. Press start/stop button



Lifting points




| NISSAN AUTOMOTIVE EUROPE SAS |
|--|
| in co-operation with Moditech Rescue Solutions |
| Nov2020 |

| Document N° | Version N° | Page N° |
|-----------------------|------------|---------|
| S ΙΝΙν Λ ΛΕ16ν1νννννν | 03 | 2/4 |

Disable direct hazards / safety regulations


Access to the engine compartment







Disconnect the 12 Volts battery






- 1. Switch off the ignition
- 2. Disconnect the negative terminal (-)
- Disconnect the positive 3. terminal (+)




ALWAYS WEAR APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT (PPE).

4. Access to the occupants

High strength steel in body



High strength steel in door Steering column adjustment





Seat adjustment



Glass types:

- A. Laminated glass.
- Tempered glass.



| NISSAN AUTOMOTIVE EUROPE SAS |
|--|
| in co-operation with Moditech Rescue Solutions |
| Nov2020 |

| Document N° | Version N° | Page N° | | |
|-------------------|------------|---------|--|--|
| SJNxAAF16x1xxxxxx | 03 | 3/4 | | |

Nissan Juke Type: F16, 5dr SUV (2019 -) - Additional Pages

5. Stored energy / liquids / gases / solids



12V





R-1234yf 450 <u>+</u>25 g









46 L






6. In case of fire



USE WATER



GAS STRUT, RISK OF MISSILE EFFECT



8. Towing / transportation / storage

Recovery hook storage



Location front hook




Location rear hook



Towing precautions











10. Explanation of pictograms used

| | General warning sign | ® | Flammable |
|---|---|----------|----------------------------------|
| * | Warning; low temperature | | Hazardous to the human health |
| * | Air-conditioning component | | Explosive |
| B | Hybrid Electric Vehicle on fuel of liquid gr. 2 | | Corrosives |
| | Bonnet | 6 | Use water to extinguish the fire |

| NISSAN AUTOMOTIVE EUROPE SAS |
|--|
| in co-operation with Moditech Rescue Solutions |
| Nov2020 |

| Document N° | Version N° | Page N° | | |
|-------------------|------------|---------|--|--|
| SJNxAAF16x1xxxxxx | 03 | 4/4 | | |